

SPORTS TRAMP EXTREME

INSTRUCTIONS FOR 14' HEX MAGIC CAGE WITH 6-1 PIECE STEEL POLES

READ INSTRUCTIONS page 22 red book BEFORE ASSEMBLING MAGIC CAGE

ASSEMBLE THE FRAME WITH STEP 1 OF THE "ASSEMBLY INSTRUCTIONS for 16' MAGIC CAGE". WITH THE SOCKETS ON THE LEGS TO THE OUTSIDE. NOW GO TO STEP 2 TO INSTALL YOUR 6 UPRIGHT STEEL POLES. (NOTE: ~~one leg has a bar welded in as a trampoline assist - easier for an adult or older child to access the trampoline but with only one bar, it would still be difficult for a little one to access a trampoline without supervision and help. Position this trampoline assist leg on the side where you will have the door.~~)

UNFOLD THE MAT/CAGE AND LAY FLAT ON GROUND INSIDE THE FRAME. AT THE TOP ARE 6 V-RING ATTACHMENTS TO HOOK ONTO THE SPRINGS AT THE TOP OF THE POLES. MAKE SURE THAT THE BOTTOM OF THE CAGE HAS THE V-RINGS TO THE OUTSIDE.

HANG THE NETTING FROM THE 6 UPRIGHTS ONE AT A TIME (EITHER REMOVE UPRIGHT FROM SOCKET TO REACH SPRINGS OR STAND ON LADDER TO REACH). IT IS EASIER TO HOOK EVERY OTHER V RING FIRST THEN GO BACK AND HOOK THE OTHERS. NOW IS THE TIME TO CONNECT THE JUMPING SURFACE TO THE FRAME.

NOTE: WHEN YOU BEGIN ATTACHING THE SPRINGS, LEAVE THE FIRST AND LAST HOLES ON ALL 6 SIDES OF THE TOP RAIL TO THE END, AS THE SAFETY PADS ATTACH WITH THESE SPRINGS.

HOOK A SPRING TO THE 2ND V RING TO THE LEFT OF THE CORNER OF THE MAT AND HOOK SPRING TO 2ND HOLE FROM THE CORNER OF THE FRAME. CONTINUE AT EACH CORNER UNTIL 1 SPRING IS CONNECTED TO THE LEFT OF EACH CORNER OF THE TRAMPOLINE. NOW CONNECT THE SPRING 2ND FROM THE RIGHT OF EACH CORNER. YOU WILL NOW HAVE 2 SPRINGS IN EACH CORNER ATTACHED TO THE MAT AND NETTING. NOW YOU CAN CONTINUE CONNECTING 2 SPRINGS ON EACH SIDE, THEN 2 MORE SPRINGS ON EACH SIDE UNTIL ALL V-RINGS ON MAT/CAGE ARE ATTACHED WITH THE FRAME. THE REMAINING V-RINGS IN THE CORNERS OF THE MAT ARE USED TO ATTACH THE SAFETY PADS.

STEP 6

PLACE ONE SAFETY PAD ON EACH SIDE WITH THE LONGER SIDE TO THE OUTSIDE. SLIDE THE SPRING THROUGH THE SLEEVE ON THE SAFETY PAD AND ATTACH THE SPRING TO THE JUMPING MAT THEN TO FRAME. CONTINUE THIS PROCESS UNTIL ALL 6-SAFETY PADS ARE IN PLACE. YOUR ASSEMBLY IS NOW COMPLETE.

ENJOY YOUR MAGIC CIRCLE TRAMPOLINE!